



6 Monthly Maintenance Procedure

This should only take 1 minute.

This is a quick guide explaining how to lubricate and maintain your Xtreme 3* Cylinder. You're not going to need any tools but you will need some graphite flakes and the key to the door. Graphite Flakes can be purchased in 2g & 30g in online or in store at Handle Trade.

- 1. Apply the powder** by tapping the flakes onto the key so some of the graphite is on the length of the key take care by covering carpets or flooring as this may mark.
- 2. Lubricate the cylinder** Insert the key with the graphite flakes on into the keyway and turn the key and pull it in and out of the cylinder several times as if you are locking or unlocking your door.
- 3. Remove the key** Remove the key and turn it upside down. And do the same as above on the reverse side of the key.
- 4. Finish** The Above process needs repeating every six months before winter and the beginning of summer to help keep your Xtreme cylinder working smoothly.



2g



30g